




TABELLA ATTACCHI

NR. COLONNETTE	INTERASSE FORI	Ø ALESAGGIO	Ø COLONNETTE	Ø FORI
4	120	80	14	16
4	275	221	18	20
5	112	66,6	14	16
5	115	80	14	16
5	130	45	14	16
5	130	80	16	18
5	130	90	14	16
5	139,7	101,7	16	18
5	140	94	14	16
5	160	120	14	17
5	275	221	20	27
5	335	280	22	23
5	335	281	22	27
5	335	290	22	24
5	404	364	18	20
6	120	80	18	20
6	140	94	14	16
6	152,4	117,4	16	18
6	165	115	16	18
6	205	161	18	21,5
6	210	150	18	19
6	215	180	14	16
6	280	240	14	17
6	285	250,5	16	17





NR. COLONNETTE	INTERASSE FORI	Ø ALESAGGIO	Ø COLONNETTE	Ø FORI
6	325	285	18	20
6	325	291	16	18
6	335	291	18	21,5
6	425	380	16	18
6	510	470	16	18
8	152,4	110,2	18	19
8	165	130	14	16
8	200	151	18	20
8	203,2	140	20	21
8	203,2	150,5	19	20
8	203,2	152,4	18	19
8	203,2	153	18	20
8	205	161	18	21,5
8	220	170	22	27
8	275	221	18	21,5
8	280	220	18	21,5
8	330	291	16	19
8	366	324	20	22
8	405	364	16	17
10	335	281	22	24
10	335	291	20	24
12	335	281	22	24
12	425	370	22	24

